


Exploded view/ Sprängskiss



Nr.	Art Nr.	Description
1	9472-B	Aerator
2	9339	Handle shower
3	9472-D	Mixer
4	9087	Flexible hose
5	9472-F	Vertical lower tube
6	9472-G	Flexible hose red
7	9472-H	Flexible hose blue
8	9472-I	Deco-cover
9	9472-J	Fixed stand
10	9472-K	Expansion screws
11	9300-F	Diverter cartiridge
12	9300-A	Thermost. cartiridge
13	9209627	Showerhead holder
14	9209626	Handle with logo